

FULL PRODUCT GUARANTEE MAINTENANCE GUIDELINES

Interior

Material
 Locks
 Sliding Gear
 components steel
 components plastic
 Cleaning Intervals
 Cleaning Method

C5M (50m - 2km from shoreline)			C5 (2km - 5km from shoreline)			C4 (5km - 15km from shoreline)			C3 (15km+ from shoreline)		
Security	Lite	Hampton	Security	Lite	Hampton	Security	Lite	Hampton	Security	Lite	Hampton
10 years	10 years	1	10 years	10 years	1	10 years	10 years	1	10 years	10 years	1
5 year	5 year	N/A	5 year	5 year	N/A	5 year	5 year	N/A	5 year	5 year	N/A
5 year	5 year	1	5 year	5 year	1	5 year	5 year	1	5 year	5 year	1
3 year	5 year	1	5 year	5 year	1	5 year	5 year	1	5 year	5 year	1
12 years	12 years	1	12 years	12 years	1	12 years	12 years	1	12 years	12 years	1
2-4weeks min	2-4weeks min	2-4weeks min	2 Months min	2 Months min	2 Months min	4 Months min	4 Months min	4 Months min	6 Months min	6 Months min	6 Months min
2&3	2&3	3	2	2	3	2	2	3	2	2	3

Exterior

Material
 Locks
 Sliding Gear
 components steel
 components plastic
 Cleaning Intervals
 Cleaning Method

Security	Lite	Hampton	Security	Lite	Hampton	Security	Lite	Hampton	Security	Lite	Hampton
5 year	5 year	n/a	5 year	5 year	n/a	10 year	10 year	n/a	10 years	10 years	n/a
5 year	5 year	n/a	5 year	5 year	n/a	5 year	5 year	n/a	5 year	5 year	n/a
5 year	5 year	n/a	5 year	5 year	n/a	5 year	5 year	n/a	5 year	5 year	n/a
3 year	3 year	n/a	3 year	3 year	n/a	3 year	3 year	n/a	5 year	5 year	n/a
12 years	12 years	n/a	12 years	12 years	n/a	12 years	12 years	n/a	12 years	12 years	n/a
1-2weeks min	1-2weeks min	n/a	2-4 Weeks	2-4 Weeks	n/a	2-3 Months	2-3 Months	n/a	6 Months	6 Months	n/a
1	1	n/a	1	1	n/a	1	1	n/a	1	1	n/a

FULL PRODUCT GUARANTEE MAINTENANCE GUIDELINES

Cleaning Method 1

Rinse shutters with running water on both sides.

Rinse the inside of each side channel with running water for at least 5 seconds

Use a premium quality (salt free) car wash liquid, mixed with water (as per liquid manufacturer's directions) and a soft cotton cloth to clean the entire unit.

Never use abrasive cleaners, detergent based cleaners or solvent based cleaners such as scouring agents, dishwashing liquids, washing powders, thinners etc as these could adversely affect the expected life of the product.

Hard to reach areas may require the use of a soft nylon bristle brush such as a dishwashing brush.

Dry the unit with a soft cotton cloth or chamois.

Always note: Salt is the enemy and this is what we are trying to remove in this process.

Cleaning Method 2

Use a premium quality (salt free) car wash liquid, mixed with water (as per liquid manufacturer's directions) and a soft cotton cloth to clean the entire unit.

Never use abrasive cleaners, detergent based cleaners or solvent based cleaners such as scouring agents, dishwashing liquids, washing powders, thinners etc as these could adversely affect the expected life of the product.

Hard to reach areas may require the use of a soft nylon bristle brush such as a dishwashing brush.

Dry the unit with a soft cotton cloth or chamois.

Always note: Salt is the enemy and this is what we are trying to remove in this process.

Cleaning Method 3

Wipe with damp cloth.